# Power Electronics / Installation Technique

MINISTART Phase Controller IN 9017

# Translation of the original instructions





- Phase controller for resistive and motor load
- For permanent power up to 300 W
- Interference suppression limit value class B
- LED indication
- Devices available in 3 versions:

IN 9017/100: With current interface 4 ... 20 mA

and broken wire detection


IN 9017/200: With voltage interface 0  $\dots$  10 V IN 9017/211: With voltage interface 0  $\dots$  10 V,

U<sub>min</sub> adjustable, control input for


max. output current

• Width: 53 mm


#### **Block Diagrams**



# IN 9017/100



## IN 9017/200



IN 9017/211

## **Approvals and Markings**



## **Application**

- · Resistive load
- · Infrared heating
- Fan
- · Volume compressor

#### **Function**

Phase controllers robust electronic units to control the voltage by phase chopping. The Phase chopping angle is adjusted on a control input. (IN 9017/100: 4 ... 20 mA, IN 9017/200: 0 ... 10 V) verstellt.

The variant IN 9017/211 is realised with 0...10V input and voltfree contact input Q1, Q2.

When contact input Q1, Q2 is open the output remains off at 0-3 V. With 3V control voltage the voltage adjusted on potentiometer Umin is switched on. When rising the control voltage continuously up to 10 V on the input, the output voltage increases up to AC 230 V. By closing the contact on Q1,Q2 the the output supplies the max. voltage.

# Indication

LED green: Supply voltage is present

LED yellow

At IN 9017/100: Permanent on, when control current > 4 mA

flashes 1 time, when control current < 4 mA

(cable break) flashes 2 times, when mains frequency is outside limits

At IN 9017/200: Permanent on, when full voltage on motor is present

flashes 1 time, when phase gating is active

flashes 2 times, when mains frequency is outside limits

At IN 9017/211: Permanent on, when full voltage on motor is present

flashes 1 time, when phase gating is active

flashes 2 times, when mains frequency is outside limits flashes 3 times, when setpoint < 3 volt and  $Q_1$ ,  $Q_2$ 

are open

#### **Notes**

If the power semiconductor should be protected against short circuit or ground fault during operation a semiconductor fuse needs to be installed (see technical details). If not the standard line protection fuses must be used. The phase controller must not be operated with capacitive load on the output. To provide safety for people and equipment, only trained staff must work on this unit.

#### **Technical Data**

Motor	voltage
-------	---------

IN 9017/100: AC 48 V ±10 % IN 9017/100: AC 115 V ±10 % IN 9017/100: AC 230 V ±10 % IN 9017/200: AC 115 V ±10 % IN 9017/200: AC 230 V ±10 % IN 9017/211: AC 230 V ±10 % Nominal frequency: 50 / 60 Hz 300 W at AC 230 V Nominal load P<sub>N</sub>:

150 W at AC 115 V Approx. 0.1 P<sub>N</sub> Min. power:

Rated current: 1.3 A Semiconductor fuse: Max. 340 A2s

Setting range output voltage

IN 9017/100: AC 48 V AC 12 ... 36 V AC 29 ... 86 V IN 9017/100: AC 115 V IN 9017/100: AC 230 V AC 58 ... 172 V IN 9017/200: AC 115 V AC 20 ... 115 V IN 9017/200: AC 230 V AC 40 ... 230 V AC 230 V AC U<sub>min</sub> ... 230 V U<sub>min</sub> AC 80 ... 200 V IN 9017/211:

Recovery time: 200 ms Consumption: 1.4 VA

**Control input** 

IN 9017/100: 4 ... 20 mA  $R_1 = 82.5 \Omega$  $R = 50 \text{ k}\Omega$ IN 9017/200: 0 ... 10 V IN 9017/211: 0 ... 10 V  $R = 50 \text{ k}\Omega$ 

Q<sub>1</sub>, Q<sub>2</sub>, volt free

## **General Data**

Nominal operating mode: Continuous operation

Temperature range: 0 ... + 55 °C Storage temperature: - 25 ... + 75 °C

Clearance and creepage distance

Rated impulse voltage /

pollution degree: 4 kV / 3 IEC 60664-1 **FMC** 

Electrostatic discharge: 8 kV (air) IEC/EN 61000-4-2 IFC/FN 61000-4-3 HF irradiation: 10 V/m Fast transients: 2 kV IEC/EN 61000-4-4

Surge voltage

between

wires for power supply: 1 kV IEC/EN 61000-4-5 between wire and ground: 2 kV IEC/EN 61000-4-5 HF-wire guided: 10 V IEC/EN 61000-4-6 Interference suppression: Limit value class B EN 55011

Degree of protection

Housing: IP 40 IEC/EN 60529 IP 20 Terminals: IEC/EN 60529

Thermoplastic with VO behaviour Housing: according to UL subject 94

Vibration resistance: Amplitude 0.35 mm

frequency 10 ... 55 Hz, IEC/EN 60068-2-6 Climate resistance: 0 / 055 / 04 IEC/EN 60068-1

Terminal designation: EN 50005

Wire connection: 2 x 2.5 mm<sup>2</sup> solid or

2 x 1.5 mm<sup>2</sup> stranded wire with sleeve

DIN 46228-1/-2/-3/-4

Wire fixing: Flat terminals with self-lifting clamping

piece IEC/EN 60999-1 DIN-rail IEC/EN 60715

Mounting: Weight: 210 g

**Dimensions** 

Width x height x depth: 53 x 90 x 61 mm

#### **Standard Types**

IN 9017/100 AC 48 V 75 W

Article number:: 0062206

IN 9017/100 AC 115 V 150 W

Article number:: 0058431

IN 9017/100 AC 230 V 300 W

Article number:: 0065838

IN 9017/200 AC 115 V 150 W

Article number:: 0065592

IN 9017/200 AC 230 V 300 W

Article number:: 0058274

IN 9017/211 AC 230 V 300 W

Article number:: 0059425

#### **Set-up Procedure**

- 1. Wiring of the component according to connection example
- 2. Adjust required output voltage

#### Safety remarks


- Never clear fault when the device is switched on
- The user must ensure that the device and the necessary componentsare mounted and connected according to the locally applicable regulations and technical standards.
- After disconnection of the device dangerous voltages may be sensedfor several minutes on the connection terminals caused by filter capacitors.

## Attention:




This device can be started by potential-free contact, while connected directly to the mains without contactor Please note, that the load is not physically separated from the mains. Because of this the load must be disconnected from the mains via the corresponding manual motor starter.

#### **Control Characteristics**




IN 9017/200 AC 230 V




IN 9017/211


2 11.01.21 en / 335A

# **Application Examples**





# IN 9017/100



IN 9017/211

3

11.01.21 en / 335A

E. Dold & Söhne GmbH & Co	. KG • D-78120 Furtwangen	• Bregstraße 18 • Phone +49	7723 654-0 • Fax +49 7723 654356